

Acesonic 6000 / 6000 PRO

KOD 6000PRO Touch screen Firmware Update


*Note. This is for KOD 6000 Touch screen Firmware update:
Please update the firmware first, and then install your APK.*

Install Firmware → install APK


Step 1:

To confirm your firmware version


In the main menu, go to “setting”



Click into the “about”:




To check your firmware version, roll down to the bottom of the page. Note - Example shown: 20180318




Step 2:

In the main menu, click “My Apps”



Choose “UPDATE&BACKUP”

NOTE: If you can't use the touchscreen to roll to another page, please use the remote control.



Insert the USB drive with your firmware file into the back of the KOD touch screen. Please use the black connector


In the “UPDATE&BACKUP”, check “Wipe Data” and “Wipe Media”.


Please note: Please use zip file for firmware update.

Use “select” to choose the firmware file in your USB drive (example shown: 20180519), then press “update”.



Please note: Please use zip file for firmware update. It would not take unzip file.





When the system update is being processed, please do not turn the touchscreen. Once the update process is finished, the system will restart.

Please recheck the firmware version using step 1.

Once the Firmware was updated, please use the Update APK instruction to update your APK.

For latest APK update, please visit www.acesonic.com for more detail.